

Easy Tool Manual

Pistol Grip Position

1



Insert the band into the buckle. The buckle teeth shall be in the direction of the operator with the ears faced up. Bend end of band under buckle.

2



Place the band in the tool with sufficient band in the winding mandrel.

3



Press the tensioning handle several times until the buckle is tight.



Roll tool over as far as tool will go and push forward cutter handle to cut the band.



Hammer down buckle ears to complete the application.

Straight or Angle Position



Place the band in the tool with sufficient band in the winding mandrel.

2



Press the tensioning handle several times until the clamp is tight.



Roll tool over as far as tool will go and push forward cutter handle to cut the band.



Hammer down buckle ears to complete the application.